










ARROW PANEL DISPLAYS FOR INDICATING “CAUTION”

<u>Display Type</u>	<u>First Sequence</u>	<u>Second Sequence</u>	<u>Third Sequence</u>
<i>Flashing Four-Corner</i>	 A black rectangular panel with four yellow dots at the corners. The top-left and bottom-left dots are solid, while the top-right and bottom-right dots are hollow.	 A black rectangular panel with four yellow dots at the corners. The top-right and bottom-right dots are solid, while the top-left and bottom-left dots are hollow.	 A black rectangular panel with four yellow dots at the corners. The top-left and bottom-left dots are solid, while the top-right and bottom-right dots are hollow.
<i>Flashing Bar</i>	 A black rectangular panel with a horizontal row of eight solid yellow dots.	 A black rectangular panel with a horizontal row of eight hollow white dots.	 A black rectangular panel with a horizontal row of eight solid yellow dots.
<i>Flashing Diamond</i>	 A black rectangular panel with two diamond-shaped patterns of dots. The left pattern has seven solid yellow dots, and the right pattern has seven hollow white dots.	 A black rectangular panel with two diamond-shaped patterns of dots. The left pattern has seven hollow white dots, and the right pattern has seven solid yellow dots.	 A black rectangular panel with two diamond-shaped patterns of dots. The left pattern has seven solid yellow dots, and the right pattern has seven hollow white dots.